

KOHLTECH

Solutions For Every Industry & Every Build

Wireless Monitor Manual

KOHLTECH
VIDEO MANAGEMENT CENTER



Live



Playback



Evidence

PRODUCT MANUAL

Basic Settings
Sync with transmitter
Screen Navigation

Vehicle Number
Device ID
Group
Type
Longitude
Latitude
Speed

Navigating Your Wireless Monitor

1. To power on your monitor press the “Power” button as seen in image 1A and 1B.



1A. NOTE: You must also power up the DVR/Transmitter at the same time as the monitor is powered up. (This process will vary depending on build type/install).

2. Once you have powered up the monitor, press the menu button pictured below in image 2A.



3. Once you have Pressed the menu button you will see a screen as pictured in image 3A.

3A.



4. Use the arrow buttons as pictured in image 4A. to navigate to the various icons as pictured in image 4B.

4A.



4B.



5. Once you have navigated to an icon, press the OK pictured in image 4B. button to select.

Auto Paring Monitor To Transmitter

1. Power up the monitor and press the menu button pictured below in image 1A.

1A.



2. Use the arrow buttons as pictured in image 2A. to navigate to the pair icon as pictured in image 2B.

2A.



2B.



3. Once you have navigated to the pair icon pictured above, press the OK button to select.

4. Once you have selected the pair icon you will see a screen as pictured in image 4A.

4A.



5. Use the arrow buttons as pictured previously in image 2A to navigate to each camera you want to pair.

6. This will initiate an auto pair. (NOTE: Once you power on the transmitter and initiate a pair, you will have 20 seconds to be within range of a transmitter that is in pair mode.)

7. If the pair is successful you will see a check mark above the camera selected to pair. Once you exit the pair screen you will also see the camera view display on the screen. If the pair is unsuccessful please refer to the manual-pair instructions within this document.

Manual Paring Monitor To Transmitter

1. To manually pair your monitor with the wireless transmitter you must first locate the wireless transmitter as seen in image 1A. Power on the transmitter (This process will vary depending on build type/install)

1A.



2. Once you have located the transmitter you must press and hold the “Pair Button” until it shows blue as seen in image 2A. (Once the button is pressed you will see the “pairing” light blink blue.)

2A.



3. Once a blue blinking ring around the pair button is seen, return to the monitor and navigate to the main menu by pressing the menu button as seen in image 3A.



4. Use the arrow buttons as pictured in image 4A. to navigate to the pair icon as pictured in image 4B.



5. Once you have navigated to the pair icon pictured above, press the OK button to select.

6. Once you have selected the pair icon you will see a screen as pictured in image 6A.

6A.



7. Use the arrow buttons as pictured previously in image 4A to navigate to each camera you want to pair.

8. This will initiate the pair sequence. (NOTE: Once you initiate a pair, you will have 20 seconds to be within range of a transmitter that is in pair mode.)

9. If the pair is successful you will see a check mark above the camera selected to pair. Once you exit the pair screen you will also see the camera view display on the screen.

Technical Support Contact Guide

For further assistance please contact KOHLTECH at:

support@kohl-tech.com

877.708.7803

www.kohltechnology.com/contact